



INSTALLATION:

- STEP 1 - CUT END CAPS AS SHOWN ON END CAP DRAWING AND SLIP CAPS OVER EXHAUST PIPE MAKING SURE CAPS POINT IN OPPOSITE DIRECTION FROM EACH OTHER
- STEP 2 - CLECO AND THEN RIVET BASE TO END CAPS.
- STEP 3 - SECURE USING 2" PIPE CLAMPS
- STEP 4 - OPTIONAL: STUFF HEAT MUFF WITH STAINLESS STEEL "SCRUBBING PAD" TO INCREASE SURFACE AREA FOR MAXIMUM HEAT TRANSFER.
- STEP 5 - ATTACH 2" SCAT TUBING.

Cabin Heat Muff v1.0

For Jabiru 3300
 Designed by D. Weber