



Step 1

Remove black plastic handle. Inside will be the needed mandrel.



Step 2

Place mandrel on grommet



Step 3

Place snap ring on mandrel-

Note: pushing the snap ring down toward the fattest part of mandrel



Step 4

Place rubber on top of the barrel until it fits snug

Push down slowly with force

Note: Push **evenly** on snap ring until snap ring is on grommet.